

TABLE OF CONTENTS

1 SAFETY

INTRODUCTION	1-1
CLEANING, WAXING, & POLISHING	1-1
CONTROLLING CORROSION	1-1
PROPELLERS	1-2
LOADING	1-7
HORSEPOWER	1-7
FLOTATION	1-7
BOATING ACCIDENT REPORTS	1-9

2 TUNING

INTRODUCTION	2-1
TUNE-UP SEQUENCE	2-2
COMPRESSION CHECK	2-3
SPARK PLUG INSPECTION	2-3
IGNITION SYSTEM	2-4
TIMING & SYNCHRONIZING	2-4
BATTERY CHECK	2-5
CARBURETOR ADJUSTMENT	2-6
FUEL PUMPS	2-8
CRANKING MOTOR & SOLENOID	2-9
INTERNAL WIRING HARNESS	2-9
WATER PUMP CHECK	2-10
PROPELLER	2-11
LOWER UNIT	2-11
BOAT TESTING	2-12

3 MAINTENANCE

INTRODUCTION	3-1
OUTBOARD SERIAL NUMBERS	3-2
LUBRICATION	3-2
PRESEASON PREPARATION	3-3
Units With Oil Injection	3-5
FIBERGLASS HULLS	3-6
BELOW WATERLINE SERVICE	3-7
SUBMERGED ENGINE SERVICE	3-7
PROPELLER SERVICE	3-9
POWER TRIM/TILT	3-9
INSIDE THE BOAT	3-10
LOWER UNIT	3-10
WINTER STORAGE	3-11
Units With Oil Injection	3-12

4 FUEL

INTRODUCTION	4-1
GENERAL CARBURETION INFO.	4-1
FUEL SYSTEM	4-4
Leaded Gasoline & Gasohol	4-4
Removing Fuel From System	4-5
TROUBLESHOOTING	4-5
Fuel Problems	4-6
"Sour" Fuel	4-6
Fuel Pump Test	4-7
Rough Engine Idle	4-10
Excessive Fuel Consumption	4-10
CARBURETOR MODELS	4-11
SIDE BOWL AND BACK DRAG	
CARBURETORS -- REFERENCED	
"A" IN APPENDIX	4-11
Removal & Disassembling	4-12
Cleaning & Inspecting	4-14
Assembling	4-18
INTEGRAL FUEL PUMP	
CARBURETOR -- REFERENCED	
"B" IN APPENDIX	4-23
Removal & Disassembling	4-25
Cleaning & Inspecting	4-25
Assembling	4-26
CENTER ROUND BOWL	
CARBURETOR -- REFERENCED	
"C" IN APPENDIX	4-30
Removal & Disassembling	4-30
Cleaning & Inspecting	4-32
Assembling	4-32
MIKUNI RECTANGULAR BOWL	
SIDE-DRAFT CARBURETOR	
REFERENCED "D"	
IN APPENDIX	4-37
Removal & Disassembling	4-37
Cleaning & Inspecting	4-40
Assembling	4-41

4 FUEL (CONTINUED)

MIKUNI ROUND BOWL SIDE-DRAFT CARBURETOR REFERENCED "E" IN APPENDIX	4-44
Removal & Disassembling	4-44
Cleaning & Inspecting	4-46
Assembling	4-48

TILLOTSON "BC" RECTANGULAR BOWL -- DOUBLE FLOAT CARBURETOR WITH INTEGRAL FUEL PUMP -- REFERENCED "F" IN APPENDIX	4-51
Removal & Disassembling	4-51
Cleaning & Inspecting	4-53
Assembling	4-55

WALBRO "WMC" RECTANGULAR BOWL -- DOUBLE FLOAT CARBURETOR WITH INTEGRAL FUEL PUMP -- REFERENCED "G" IN APPENDIX	4-58
Removal & Disassembling	4-59
Cleaning & Inspecting	4-61
Assembling	4-63

ROUND BOWL -- SINGLE FLOAT CARBURETOR -- STAMPED "F" WITH "KEIKHIN" INTEGRAL FUEL PUMP REFERENCED "H" IN APPENDIX	4-68
Removal & Disassembling	4-68
Cleaning & Inspecting	4-72
Assembling & Installation	4-72

FUEL PUMP	4-76
Theory of Operation	4-76
Pressure Check	4-79
Removal	4-79
Cleaning & Inspecting	4-80
Assembling	4-80

OIL INJECTION	4-81
Operation	4-82
Troubleshooting	4-82
Preparation For Use	4-84

5 IGNITION

INTRODUCTION	5-1
SPARK PLUG EVALUATION	5-2
WIRING HARNESS	5-5

TYPE I IGNITION SYSTEM

PHELON -- MAGNETO WITH POINTS	
Description	5-6
Troubleshooting	5-7
Servicing	5-10
Disassembling	5-10
Cleaning & Inspecting	5-12
Assembling	5-15

TYPE II IGNITION SYSTEM

THUNDERBOLT -- FLYWHEEL PHASE MAKER -- WITH POINTS	
Description	5-18
Troubleshooting	5-18
Servicing	5-23
Phase Maker W/O Module	
Disassembling	5-24
Assembling	5-26
Phase Maker With Module	
Disassembling	5-27
Assembling	5-29

TYPE III IGNITION SYSTEM

THUNDERBOLT -- FLYWHEEL CD -- POINTLESS	
Description	5-31
Troubleshooting	5-32
Servicing	5-34
Removal	5-34
Installation	5-35

TYPE IV IGNITION SYSTEM

THUNDERBOLT -- FLYWHEEL CD -- COIL PER CYLINDER	
Description	5-36
Troubleshooting	5-37
Disassembling	5-41
Assembling	5-44

6 TIMING AND SYNCHRONIZING

INTRODUCTION & PREPARATION	6-1
MODEL 39, 40, 60, 75, & 110 1965-1969	6-2
MODEL 200 1965-1966	6-3
MODEL 350 1965-1969	6-4
MODEL 200 1967-1969	6-6
MODEL 40 1970	6-7
MODEL 200 1970-1977 TO SERIAL NO. 4709592 OF 1978	6-8
MODEL 75 & 110 1970	
MODEL 40, 75 & 110 1971-1974	
MODEL 45 1975-1979	
MODEL 4.5 1979-1985	
MODEL 4.0 1986 -- Mid '87	
MODEL 90cc 1986-87	6-10

6 TIMING AND SYNCHRONIZING (CONT)

MODEL 400 1970-1971	6-11
MODEL 402 1972-1979	
MODEL 40 1979-1983	
MODEL 35 1984-89	6-13
MODEL 40 1976-1981	6-14
MODEL 75 & 110 1975-1979	
MODEL 7.5 & 9.8 1979-1985	6-16
MODEL 200 1978-1981	
SERIAL NO. 4709592 & UP	6-17
MODEL 3.5 & 3.6 1980-1985	6-18
MODEL 18 & 25 1980-1983	
MODEL 18XD & 25XD 1984-1985	
MODEL 20 1979-80 & 1986 & ON	6-19
MODEL 25 1986 & ON	6-19
Model 2.2 -- 1984-89 and	
Model 3.0 -- 1990 & on	6-21
MODEL 6.0, 8.0, 9.9, 15, & 210cc	
1986 & ON	6-21
MODEL 4.0 Mid 1987 & ON	
MODEL 5.0 1988 & ON	6-23

7 ELECTRICAL

INTRODUCTION	7-1
BATTERIES	7-1
Construction	7-2
Ratings	7-2
Jumper Cables	7-5
Storage	7-6
THERMOMELT STICKS	7-6
TACHOMETER	7-7
ELECTRICAL SYSTEM	
GENERAL INFORMATION	7-7
CHARGING CIRCUIT SERVICE	7-8
CRANKING MOTOR	
CIRCUIT SERVICE	7-9
Troubleshooting	7-10
CRANKING MOTOR SERVICE	7-13
Disassembling Large Motor	7-14
Disassembling Small Motor	7-15
Cleaning & Inspecting	7-17
TESTING CRANKING MOTOR	7-18
ASSEMBLING	
Large Motor	7-20
Small Motor	7-23

8 POWERHEAD

INTRODUCTION	8-1
Chapter Organization	8-3

POWERHEAD "A"

SPLIT BLOCK WITHOUT HEAD	
INTERNAL REED BOX AROUND	
THE CRANKSHAFT	
(See Tune-up Specs. Last Col.)	
Removal & Disassembling	8-5
Assembling	8-11
Installation	8-21

POWERHEAD "B"

SPLIT BLOCK WITHOUT HEAD	
EXTERNAL REED BLOCK	
(See Tune-up Specs. Last Col.)	
Removal & Disassembling	8-24
Assembling	8-34
Installation	8-43

POWERHEAD "C"

SPLIT BLOCK WITH HEAD	
REEDS INSTALLED UNDER	
THE CRANKSHAFT	
(See Tune-up Specs. Last Col.)	
Removal & Disassembling	8-47
Assembling	8-55
Installation	8-58

CLEANING & INSPECTING

ALL POWERHEADS	8-62
Reed Block Service	8-62
Crankshaft & End Cap Bearings	8-64
Connecting Rods	8-65
Piston Service	8-67
Honing Procedures	8-69
Cylinder Block Service	8-70

9 LOWER UNIT

DESCRIPTION	9-1
CHAPTER ORGANIZATION	9-1
TROUBLESHOOTING	9-2
PROPELLER REMOVAL	9-4

LOWER UNIT TYPE "A"

NO REVERSE GEAR	
(See Lower Unit Table in Appendix)	
Description	9-6
Removal & Disassembling	9-6
Cleaning & Inspecting	9-12
Assembling	9-15
Installation	9-23

LOWER UNIT TYPE "B"

REVERSE CAPABILITY	
(See Lower Unit Table in Appendix)	
Description	9-25
Removal & Disassembling	9-25
Cleaning & Inspecting	9-33
Assembling	9-37
Installation	9-49

9 LOWER UNIT (CONTINUED)

LOWER UNIT TYPE "C"

REVERSE CAPABILITY	
UNIQUE SHIFT ARRANGEMENT (See Lower Unit Table in Appendix)	
Description	9-51
Removal & Disassembling	9-51
Cleaning & Inspecting	9-53
Assembling	9-55
Installation	9-58

LOWER UNIT TYPE "D"

NO REVERSE CAPABILITY	
WATER PUMP INSTALLED ON PROPELLER SHAFT (See Lower Unit Table in Appendix)	
Disassembling	9-59
Cleaning & Inspecting	9-64
Assembling	9-66

10 TRIM/TILT

INTRODUCTION	10-1
CHAPTER ORGANIZATION	10-1
MECHANICAL TILT PIN ALL UNITS	10-2
DESCRIPTION AND OPERATION TRIM/TILT SYSTEM	10-3
SPECIAL INSTRUCTIONS	10-5
SERVICING TRIM TILT SYSTEM	
Hydraulic Bleeding	10-6
Troubleshooting	10-8
Testing Components	10-8
Cleaning & Inspecting	10-9
Installation	10-9
Solenoid Testing	10-10
Hydraulic Trim Service	10-12
Hydraulic Pump Service	10-14
Electric Motor Service	10-17

11 REMOTE CONTROLS

INTRODUCTION	11-1
COMMANDER CONTROL SHIFT BOX	
Removal & Disassembling	11-2
Cleaning & Inspecting	11-9
Assembling & Installation	11-11

12 HAND REWIND STARTER

INTRODUCTION	12-1
TYPE "A" (See Introduction)	
Removal & Disassembling	12-3

Cleaning & Inspecting	12-6
Assembling & Installation	12-8

TYPE "B" (See Introduction)

Removal & Disassembling	12-15
Cleaning & Inspecting	12-16
Assembling & Installation	12-17

TYPE "C" (See Introduction)

Removal & Disassembling	12-19
Cleaning & Inspecting	12-22
Assembling & Installation	12-22

TYPE "D" (See Introduction)

Removal & Disassembling	12-25
Cleaning & Inspecting	12-28
Assembling & Installation	12-29

TYPE "E" (See Introduction)

Removal & Disassembling	12-34
Cleaning & Inspecting	12-36
Assembling & Installation	12-36

TYPE "F" (See Introduction)

Removal & Disassembling	12-37
Cleaning & Inspecting	12-40
Assembling & Installation	12-40

TYPE "G" (See Introduction)

Removal & Disassembling	12-44
Cleaning & Inspecting	12-47
Assembling & Installation	12-49

TYPE "H" (See Introduction)

Removal & Disassembling	12-52
Cleaning & Inspecting	12-56
Assembling & Installation	12-56

APPENDIX

METRIC CONVERSION CHART	A-1
ENGINE SPECIFICATIONS AND TUNE-UP ADJUSTMENTS	A-2
CARBURETOR JET SIZE/ ELEVATION CHART	A-13
PISTON & CYLINDER SPECS.	A-14
REED STOP OPENING	A-15
LOWER UNIT OIL CAPACITY AND GEAR CHART	A-16
LOWER UNIT TYPE AND GEAR BACKLASH TABLE	A-17
STATOR AND COIL CHECKS	A-18
TORQUE VALUES - COMPLETE UNIT ALL MODELS	A-24

WIRING DIAGRAMS

Model 350 Elec. 1965-69	A-34
-------------------------	------

Model 402 Manual 1976-78;		
Model 40 Manual 1979-81	A-34	
Model 60 Elec. 1965-68;		
Model 110 Elec. 1965-69;		
Model 200 Elec. 1965-71	A-35	
Model 400 Elec. 1970-71	A-36	
Model 200 Elec. 1972	A-37	
Model 402 Elec. 1972-74	A-38	
Model 200 Elec. 1973-75	A-39	
Model 200 w/Alternator 1973-78	A-39	
Model 200 Elec. 1976-78;		
Model 20 (20hp) 1979-80	A-40	
Model 75 & 110 Manual 1975;		
Model 40 Manual 1976-80	A-41	
Model 75 & 110 Manual		
w/Alternator 1976-78		
Model 7.5 and Model 9.8		
w/Alternator 1979-85	A-41	
Model 75 & 110 1976-78;		
Model 7.5 & 9.8		
w/o Alternator 1979-85	A-42	
Model 40 Manual 1970-74;		
Model 4.5 1979-85;		
Model 4.0 1986-Mid 1987	A-42	
Model 4.0 Mid 1987 & On;		
Model 5.0 1988 & On and		
Model 90cc -- 1986-87	A-43	
Model 402 Elec. 1975;		
Model 40 1979-81	A-44	
Model 402 Manual 1976-78;		
Model 40 Manual 1979-81	A-44	
Model 18 Manual 1981-83;		
Model 18XD Manual 1984-85;		
Model 25 Manual 1980-83;		
Model 25XD Manual 1984-85;		
Model 6.0, 8.0, 9.9, 15, 20, 25,		
210cc Manual 1986 & On	A-45	
Model 18 Elec. 1981-83;		
Model 18XD Elec. 1984-85;		
Model 25 Elec. 1980-83;		
Model 25XD Elec. 1984-85;		
Model 6.0, 8.0, 9.9, 15, 20, 25,		
& 210cc Elec. 1986 & On		
All w/o Remote Control	A-46	
Model 18 Elec. 1981-83;		
Model 18XD Elec. 1984-85;		
Model 25 Elec. 1980-83;		
Model 25XD Elec. 1984-85;		
Model 6.0, 8.0, 9.9, 15, 20, 25,		
& 210cc Elec. 1986 & On		
All w/Remote Control	A-47	
Model 35 Manual 1984-89 and		
Model 40 Manual 1982-83	A-48	
Model 35 Elec. -- 1984-89;		
Model 40 Elec. -- 1982-83	A-49	
Model 3.5 -- 1983-85;		
Model 3.6 -- 1980-82	A-50	
Model 2.2 -- 1984-89 and		
Model 3.0 -- 1990 & On	A-50	
Commander Remote Control	A-51	