

CDI P/N 123-7566

This unit will replace P/N: 987566.

WARNING! This product is designed to be installed by a professional marine mechanic. CDI Electronics cannot be held liable for injury or damage resulting from improper installation, abuse, neglect or misuse of this product.

NOTE: This install sheet covers the 123-7566 Electronic Shift Assist (ESA) module for boats equipped with the Delco EST electronic distributor using the 5 pin connector. If your boat is wired for a 3 and 4 pin connector, order CDI P/N: 123-7878. If your boat has any other type of distributor than a Delco, please call CDI for a cross reference.

Installation

1. Disconnect and remove the old EST module and remove it from the engine.
2. Using the original bolts, mount the new EST to the mounting bracket. Be careful not to pinch any wires behind the case.
3. Connect the wires as the original EST was connected.
4. The following is a color code/function explanation:
 - A) **Violet** - Switched 12V to power the ESA module.
 - B) **Grey/Black Stripe** - 6V clock signals from the EST Electronic Distributor for the ESA to determine the engine RPM.
 - C) **Grey/White** - 4V shift signal pulses sent to the EST Electronic Distributor during shifting.
 - D) **Black** - Engine ground reference for the ESA module.
 - E) **Blue** - Ground signal from the shift switch indicating a shift is occurring.

Troubleshooting

1. Verify all connections are correct. Inspect the connectors and make sure the wire colors and pin locations are the same on both sides of the connector.
2. Back probe the Blue wire (you may remove the wire from the connector if needed) and with the engine idling in neutral, short the Blue wire from the ESA module to engine ground. (Note: If the engine is idling too fast, the ESA will not engage). You should notice a slight drop in engine RPM. If the engine works correctly with this test, but does not work when the Blue wire is connected to the shift switch, check the shift switch and wires. If the ESA does not work with the Blue wire shorted to engine ground, recheck the engine RPM, ground wire connection and 12V power to the ESA.

