



18-1989 Stainless Steel Thermostat Housing Installation Instructions

The 18-1989 thermostat housing is supplied with 2 thermoplastic thermostat spacers (1 white, 1 blue).

To determine which spacer to use, examine the housing mounting surface on the engine. If the surface is flat-no counter bore for thermostat location-the blue spacer is used. If there is a counter bore use the white spacer.

Assemble as per illustration.

