

Model 71036 Motor Tilter

Insert end hook (A) into hand recess at the rear of the motor as shown in Fig. 1.

Position rubber legs (B) on the motor shroud as close to the opposite end where firm pressure can be absorbed (see fig. 1).

NOTE: If an adjustment is necessary to fit your motor, remove screw from casting (C) as illustrated in fig. 2 and then slide casting (C) back on tube to the position as described above. Redrill screw hole with a 1/8" bit. Reinsert and secure screw in position. Cut off excess tube with a hacksaw.

IMPORTANT: BE SURE MOTOR IS FREE TO TILT BEFORE PULLING BACK. USE A SMOOTH, STEADY PULL.

FIG. 1



FIG. 2

