






ELECTRICAL PRODUCTS

RotoSwitch® Rotary Switches

Replacement Knobs. All include rubber umbrella seal. Original Ergotech design knob.			
 <p>**MP79710 Mushroom gray knob with light tube for use with light module</p>	 <p>**MP79730 *MP79732 Tan knob with light tube. Use with illumination module.</p>	 <p>**MP79740 *MP79742 Black knob with black indicator.</p>	 <p>**MP79751 *MP79752 Black knob with white indicator.</p>
 <p>**MP79760 *MP79762 Black knob with light tube. Use with illumination module.</p>	 <p>**MP78370 *MP78372 Black knob with light tube for use with light module.</p>	<p>Mounting Accessories for RotoSwitch®.</p>  <p>**MP78960 *MP78962 Anti-rotation collar. Use when installing non-illuminated RotoSwitches in very thin dash panels. This adapter prevents the switch from "slipping" if excessive force is used to actuate the switch.</p>	
<p>Illumination Module. Add flexibility and function to any installation of RotoSwitch® rotary switches. By using a variety of colored lenses, the status of each switch – "Off", "On-1", "On-2" – can instantly be determined.</p>			
  <p>**MP78870 *MP78872</p>	  <p>**MP78880 *MP78882</p>	  <p>**MP78910 *MP78912</p>	
  <p>**MP78920 *MP78922</p>	  <p>**MP78942 ①</p>	  <p>**MP78950 *MP78952</p>	

① Available in Bulk Only

* Bulk - 100 pieces per carton

** Clamshell

C=Clear B=Black G=Green R=Red