
INSTRUCTION SHEET 319293

When using this switch as a service replacement on 25 through 65 H.P. models, the 1/2" long screws and washers supplied must be used. When using this switch on 85 through 135 H.P. models, the 5/16" long screws and washers supplied must be used.







Printed in the United States.


©2004 BRP US Inc. All rights reserved.

TM, ® Trademarks and registered trademarks of Bombardier Recreational Products Inc. or its affiliates.



INSTRUCTION SHEET 319293

When using this switch as a service replacement on 25 through 65 H.P. models, the 1/2" long screws and washers supplied must be used. When using this switch on 85 through 135 H.P. models, the 5/16" long screws and washers supplied must be used.







Printed in the United States.

©2004 BRP US Inc. All rights reserved.

TM, ® Trademarks and registered trademarks of Bombardier Recreational Products Inc. or its affiliates.

