





## Starter Assembly P/N 393617

## **Safety Considerations**

These instructions will alert you to certain things you should do very carefully. If you don't, you could . . .

- hurt yourself, or bystanders
- hurt boat operator, passengers
- damage the machinery

Safety symbol, An appears next to information important to prevent you and others from being hurt.

Remove shipping retainer from shoulder screw prior to installing starter assembly. Use care to hold starter halves together until mounting screw is engaged in mounting hole.

After starter is securely mounted, remove loop from rope and feed rope through opening in lower motor cover. Place bumper and handle over rope and tie a knot as shown in illustration.

