

18-5775
SWITCH BOX MOUNTING
Special Instructions

1. Fasten one end of black ground wire (supplied with switch box) to switch box with self-tapping screw, as shown in Figure 1.
2. Fasten other end of black ground wire to a good ground on engine.




Figure 1. Black Ground Wire Attached to Switch Box

3. If engine has an orange color lead that connects to switch box, connect lead to terminal marked "BLK-YEL".