

## 0375792 - CARBURETOR FLOAT REPLACEMENT

1. Install the float in your carburetor.
2. Check the parallel relationship of the float to the carburetor gasket surface.
3. If the float is not parallel, sand the Needle Contact Surface until it is parallel. This may require a few sanding and checking cycles. The amount removed is dependent on how the float fits in your carburetor (~.01-.02).
4. The Float Drop Tab may require sanding also.

