

## TROUBLESHOOTING GUIDE

No. of blinks of MIL	MIL	Probable problem part	Page
MIL does not come ON or does not blink.		<ul style="list-style-type: none"> <li>• Open circuit in MIL wire</li> <li>• Blown MIL bulb</li> <li>• Open circuit in ECM ground wire</li> <li>• Faulty ECM</li> </ul>	5-16, 20
MIL stays ON.		<ul style="list-style-type: none"> <li>• Short circuit in service check connector wire</li> <li>• Short circuit in MIL wire</li> <li>• Short circuit in sensor system power supply line</li> <li>• Open circuit in power supply line for ECM</li> <li>• Faulty ECM</li> </ul>	5-17
1		<ul style="list-style-type: none"> <li>• Disconnected oxygen sensor connector</li> <li>• Short or open circuit in oxygen sensor wire</li> <li>• Faulty oxygen sensor</li> <li>• Spark plug misfire</li> </ul>	5-26
3		<ul style="list-style-type: none"> <li>• Disconnected MAP sensor connector</li> <li>• Short or open circuit in MAP sensor wire</li> <li>• Faulty MAP sensor</li> </ul>	5-28
4		<ul style="list-style-type: none"> <li>• Disconnected CKP sensor connector</li> <li>• Short or open circuit in CKP sensor wire</li> <li>• Faulty CKP sensor</li> </ul>	5-30
6		<ul style="list-style-type: none"> <li>• Disconnected ECT sensor connector</li> <li>• Short or open circuit in ECT sensor wire</li> <li>• Faulty ECT sensor</li> </ul>	5-31
7		<ul style="list-style-type: none"> <li>• Disconnected TP sensor connector</li> <li>• Short or open circuit in TP sensor wire</li> <li>• Faulty TP sensor</li> </ul>	5-33
8		<ul style="list-style-type: none"> <li>• Disconnected TDC sensor 1 connector</li> <li>• Short or open circuit in TDC sensor 1 wire</li> <li>• Faulty TDC sensor 1</li> </ul>	5-30
10		<ul style="list-style-type: none"> <li>• Disconnected IAT sensor connector</li> <li>• Short or open circuit in IAT sensor wire</li> <li>• Faulty IAT sensor</li> </ul>	5-35
13		<ul style="list-style-type: none"> <li>• Disconnected BARO sensor connector</li> <li>• Short or open circuit in BARO sensor wire</li> <li>• Faulty BARO sensor</li> </ul>	5-37
14		<ul style="list-style-type: none"> <li>• Disconnected IAC valve connector</li> <li>• Short or open circuit in IAC valve wire</li> <li>• Faulty IAC valve</li> </ul>	5-45

No. of blinks of MIL	MIL	Probable problem part	Page
21 (BF225A)		<ul style="list-style-type: none"> <li>• Disconnected VTEC solenoid valve connector</li> <li>• Short or open circuit in VTEC solenoid valve wire</li> <li>• Faulty VTEC solenoid valve</li> </ul>	5-43
23		<ul style="list-style-type: none"> <li>• Disconnected knock sensor connector</li> <li>• Short or open circuit in knock sensor wire</li> <li>• Faulty knock sensor</li> </ul>	5-39
24		<ul style="list-style-type: none"> <li>• Disconnected overheat sensor 1 connector</li> <li>• Short or open circuit in overheat sensor 1 wire</li> <li>• Faulty overheat sensor 1</li> </ul>	5-56
25		<ul style="list-style-type: none"> <li>• Disconnected overheat sensor 2 connector</li> <li>• Short or open circuit in overheat sensor 2 wire</li> <li>• Faulty overheat sensor 2</li> </ul>	5-56
26		<ul style="list-style-type: none"> <li>• Disconnected oil pressure switch (high pressure side) connector</li> <li>• Short or open circuit in oil pressure switch (high pressure side) wire</li> <li>• Faulty oil pressure switch (high pressure side)</li> </ul>	5-96
41		<ul style="list-style-type: none"> <li>• Disconnected oxygen sensor heater circuit connector</li> <li>• Short or open circuit in oxygen sensor heater circuit wire</li> <li>• Faulty oxygen sensor heater circuit</li> <li>• Spark plug misfire</li> </ul>	5-26
58		<ul style="list-style-type: none"> <li>• Disconnected TDC sensor 2 connector</li> <li>• Short or open circuit in TDC sensor 2 wire</li> <li>• Faulty TDC sensor 2</li> </ul>	5-30

No. of blinks of MIL	MIL	Probable problem part	Page
7, 13		Open circuit in sensor output voltage line (brown/white)	5-33 and 37
1, 6, 13, 7, 10, 24, 25		Open circuit in sensor ground line (green/red)	5-26, 31, 37, 33, 35 and 56